

Shoe and ShoeSecure Preparation -Fitting to a New Shoe-



1: Select the correct shoe size and adjust for fitting



2: Stamp the stud holes one inch from the end of the heels



3: Tap the hole with a Whitworth 3/8 thread



4: Place the shoe as tight against the back and sides of the ShoeSecure as possible



5: Punch through the centre of the stud hole to mark the ShoeSecure



6: Use a 12 mm bit to drill through the punch marks



To continue using the same set of ShoeSecures after routine re-shoeing, ask your farrier to use the old shoes as templates for stud hole positioning in the new shoes.